

Instructions for the SHARE range of tables

Handling:

It is important to handle the table tops with care. Do not subject the edges to heavy loads once the packaging has been removed.

Product description:

The SHARE table frame is made from high-grade stainless steel. Each table is hand-made. As each table is unique, there will be slight differences from one frame to another. The SHARE table is supplied with either a hardened glass table top or a ceramic table top.

Assembly (we recommend having 2 persons for the assembly):

Start by wiping the socket set screws with acid-free oil. Take note that one of the jambs is imprinted with a logo so that the jamb can be placed correctly during assembly. Place one set of legs on a plane surface and connect the two jambs vertically using 4 socket set screws, being careful not to wring the jambs into place. Do not tighten the screws too much. Connect the other leg onto the jambs and fasten with the remaining screws. We recommend being 2 persons when lifting the table frame to its upright position. Before placing the table top onto the frame, affix the non-slip pads (enclosed) evenly onto the jambs. All table tops are marked underneath to prevent them being turned upside down. The table construction is such that the table top is not screwed to the frame but simply rests on the non-slip pads on top of the frame. The non-slip pads prevent moisture from accumulating between top and frame.

Day-to-day use:

The table top essentially requires only minimal maintenance. We recommend that the table is wiped after use, and cleaned when necessary, using a mild detergent or household cleaner. The table top is suitable for outdoor use all year round. However, in order to maintain its colour and appearance, we recommend that the table top is covered with a furniture cover during the winter months or when the table is not in use for a longer period of time.

Moving or pulling items with a rough underside across the table can cause scratches.

Regular maintenance:

Although the frame is made from stainless steel, tarnishing can occur in the form of flash rust. Products that are used in areas near coasts, close to a swimming pool or in industrial areas are especially prone to tarnish, which can usually be removed using a stainless steel cleaner. It is important that tarnish is removed within a short time.

IMPORTANT!

Regular cleaning with water containing soap helps to protect the stainless steel surface and minimises the effects of chlorine, etc. We further recommend that the frame and screws are wiped with acid-free oil at least twice a year to minimise tarnish.

Winter storage:

We recommend that the table is stored under a furniture cover during the winter months.